TeachSmart® Quick Start Guide




LAUNCHING THE TEACHING GUIDE



- If you have an Interactive Whiteboard, power on your computer, unit (see image), then
 power on the projector with the included remote OR use the Standby / On button on
 your projector.
- If you have an **Interactive Display**, power on the NUC computer behind the display. The button will glow blue when the NUC is powered on.
- If the display is dark while the NUC button is blue, press the round power button on the right edge of the display itself.



 When you see the Windows desktop, touch the Wi-Fi icon in the top-right to connect, or plug in your Ethernet cable.





2









Open the Teaching Guide

 Find the Teaching Guide shortcut on your desktop and double-tap it to launch the Teaching Guide, which enables you to navigate and open the activities available by way of TeachSmart.




USING THE TEACHING GUIDE





Find Activities by Category

• The easiest way to find activities is to from the Skill Category tiles found on the Home Page. Click a Skill Category tile to open the activities that align.




USING THE TEACHING GUIDE






Find Activities by Standard

- Selecting Standards in the blue menu bar (near the top of the Home Page) enables you to search for activities based on a variety of standards.
- Select the tile that represents your center's needs and requirements.



Find Activities by Language

- Activities are available in English and Spanish.
- Note that once you have begun browsing, you have the option to filter or search by language.



Free Online Courses

• Need a bit more guidance? Visit Hatch's online **Learning Courses**. Hatch's Learning Management System (LMS) offers courses with completion certificates, reference materials, and contact forms to build your savvy and answer your stickiest questions. Take a course or watch a video in the Video Library. Visit: LMS.HatchEarlyLearning.com

